

Selecting the Face Driver components:

#1 Determine the Face Driver model with the type of mounting required for the machine.

#2 If mounting directly to machine spindle, verify spindle size and select appropriate spindle adapter.

- #3 Choose the center point with the diameter range closest to the center hole diameter.
- #4 Determine machine spindle rotation and driving diameter to select the correct drive pins.

Rotation is determined by looking directly at the spindle face or chuck face.

(For detailed instructions on selecting a face driver, see page 42).

Mounting Styles Available for Type 47



Morse Taper*

#1 FACE DRIVER				
Order Code	Mounting Style			
4705	#5 Morse Taper*			
4706	#6 Morse Taper*			
47FM	Flange Mount*			

* All mechanical styles can be chucked.

#2 SPINDLE ADAPTER (For direct mount only)					
Order Code	Spindle Size				
708037	A2-5				
708038	A2-6				
708039	A2-8				
708040	A2-11				

#3 CENTER POINT		#4 DRIVE PINS (6 pins required)					
Orden		Order	Counterclockwise (Right)		Clockwise (Left)		
Order Code	Center Hole Dia. Range	Code	Outer Driving Diameter	Inner Driving Diameter	Outer Driving Diameter	Inner Driving Diameter	
C4701 C4702	0.120 - 0.950 0.906 - 1.102	P4701	1.54	1.14	_	_	
		P4702	_	_	1.54	1.14	
		P4703	1.93	1.32**	_	_	
		P4704	_	-	1.93	1.32**	
		P4705	2.32	1.72**	-	_	
		P4706	-	-	2.32	1.72**	
C4703	1.063 - 1.260	P4731	1.54	1.30	-	_	
		P4732	-	-	1.54	1.30	
		P4733	1.93	1.30	-	-	
		P4734	-	-	1.93	1.30	
		P4735	2.32	1.72**	-	-	
		P4736	_	-	2.32	1.72**	
C4704	1.220 - 1.417	P4743	1.93	1.46	-	-	
		P4744	_	_	1.93	1.46	
		P4745	2.32	1.72**	-	-	
		P4746	_	-	2.32	1.72**	
C4705	1.378 - 1.575	P4753	1.93	1.62	-	-	
		P4754	_	-	1.93	1.62	
		P4755	2.32	1.62	-	_	
		P4756	_	-	2.32	1.62	
C4706	1.535 - 1.732	P4763	1.93	1.77	-	-	
		P4764	_	-	1.93	1.77	
		P4765	2.32	1.77	_	_	
		P4766	-	-	2.32	1.77	

Flange Mount*
* All mechanical styles
can be chucked.

TO ORDER: A complete unit consists of a face driver, center point and drive pins. For direct mounts, a spindle adapter must be added.

#1 Face Driver

order code: _ _ _ _

#2 Spindle Adapter
order code: _ _ _ _ _ _
(only required for direct
mount)
#3 Center Point

order code: _ _ _ _ #4 Drive Pins

order code: _ _ _ (6 pins required)

53

Call 1-800-338-0027

** Chisled edges for better gripping